

DCH DVR 6400 and DCH 6200 Installation Setup Using Basic Coaxial Cable

REMEMBER: With this setup, your TV must be set to Channel 3. You can then change the cable station on the digital box using our provided remote.

